Imperial Productions®
IPNP1034H

Diameter 30" (76.2cm)

<------------------------------------->

Materials

ArchPolymer™
an artificial wood primed white easy to install with the approved adhesive and a brad nailer. Finish joining edges with poly spackling compound. Optional Class A fire rating available. Exterior & Interior use

Click for Material Properties

GRG-NeoPlaster™
Much stronger than tradiitonal plaster Class A fire rated product. Screw & glue into place. Priming by others. Interior use.

Click for Material Properties

ResinMold®
A Flexible synaptic polymer for vaulted or curved ceilings Interior & Exterior Use

Click for Material Properties

Canopy Area 5" (12.7cm)

Note: Always use a professional certified electrician to install any electrical device that must be hard wired. These notes are guidelines only. For your situation, consult a professional and adhere to local building codes.

1) Weights: Medallions are decorative only and do not hold weight. Any fixture must be hung by the electrical recepticle threaded rod. For heavy fixtures, re-enforce the ceiling rafters to hold the weight.

2) Power: Make sure there is no power to the recepticle box.
Turn off the breaker and confirm with an electric tester.

3) Mark the Spot: Hole the medallion center to the recepticle box and trace out the outside of the medallion on the ceiling.

4) Preparation: Lightly sand and remove all dust or popcorn plaster (stucco) from the ceiling prior to install to ensure a flat surface.

5) Hole: Order your medallion with a precut specified hole or drill a hole yourself ensuring it is slightly larger than the size of the recepticle box.

6) Paint the medallion before you install - allow 24 hrs to dry

7) Apply the Adhesive. Use approved adhesive only that is safe for ArchPolymer™ - put multiple small blobs on the back side of the medallion. Use this same adhesive for Neo-Plaster-GRG.

8) Use 4 screws to temporarily hold the medallion or preferably use a brad nailer to affix the medallion to the ceiling. Use only a few brad nails as they are just holding the medallion till the adhesive dries. In the case of Neo-Plaster-GRG use screws only and countersink them to be filled later.

9) Check to make sure the medallion is level on all sides. If it is not use a small wedge to pry one side downward until all sides are even. This is the time to correct any unevenness. Make sure you have pulled the wires through the center hole.

10) Allow to dry for a few hours or overnight.

11) Fixing the gap between the medallion and the ceiling. Apply the Vinyl Spackling compound with your finger or a small flat trowel to the edges of the medallion. Let dry and sand lightly or wet sand during application. DO NOT use caulking. Caulking tends to dry out over time and shrinks. The vinyl splacking is plaster with polymers and stays flexible but can be sanded unlike caulking. Fill all countersunk screws or brad nails. Touch up with paint over spackling compound.

12) Electrical hookup - wires go though the threaded rod and should be installed by a qualified electrician.

Imperial Productions®

DIY Finishing Products

Prime-All
for Metals, ArchPolymer
GRG-NeoPlaster

Metal Leaf
Golds / Silvers / Bronzes
Coppers / Gun Metal
Water Base Lustre

Clear Coat
Flat / Satin / Hi Gloss

Japan Colors
Renaissance to Modern
31 Sophisticated Flat Finishes
Mixing and Undertones

Bulletin Enamel
Synthetic Oil Bases
High Gloss

AquaCote
Bulletin High Gloss
Water Based

1 Stoke
Lettering Enamels
Fine Line for Details

Fluorescent
For Funky Interior Design
5 Brilliant Colors

click for => Specialty Paint Prices

Glue   click for Page

UV
Protect
click for Page

Spackle
Fill in
Compound
click for Page

Name / Company: _____

Phone _____   Email _____

Billing Address: _____

City: _____   Prov / State _____

PC / Zip Code_____

Ship to Address: _____

City: _____   Prov / State _____

PC / Zip Code_____

Product Code: _____

Quantity: _____

Notes: _____